



NOTES:

1. USE R.C.P. CLASS V FOR STORM DRAIN PIPE.
2. USE P.V.C. PIPE C-900 CLASS 200 FOR WATER PIPE.
3. USE P.V.C. PIPE SDR 23.5 FOR SEWER PIPE.
4. CONCRETE SLURRY BACKFILL IS CLASS 100-E-100 PCC AND CURED AT LEAST 24 HOURS PRIOR TO PAVING.

TITLE: PIPE PROTECTION FOR SHALLOW PIPES FOR STORM, SEWER & WATER

DRAWN BY: STAFF	SCALE: NONE
REVIEWED BY: DANNY HILLSTOCK	REVISED: OCTOBER, 2019

APPROVED:

*Danny Hillstock* 11-5-19

CITY ENGINEER: DANNY HILLSTOCK LIC. NO. 70647

DATE

STANDARD PLAN

**E-6**

SHEET 1 OF 1

CITY OF HOLLISTER  
ENGINEERING DEPARTMENT